


T (Thickness)	D (Diameter)	R (Radius)	C (Fixing Centres)
6	150	75	100
10	150	75	100
6	200	100	100
10	200	100	100
6	250	125	100
10	250	125	100
6	300	150	120
10	300	150	120
6	400	200	140
10	400	200	
6	500	250	200
10	500	250	200
6	600	300	250
10	600	300	250




	N
ノトレ	3
StyleFinishDoorware	S

Drawing
M02 Offset Entrance Handles
Date 2 (0.5 / 2.0.2.2)

3/05/2023

Scale 1:2



## **Installation Instructions**

IMPORTANT! Mark and drill door from both sides.

Cut bolt to required length. Allow 30mm longer than door thickness.

Screw stands together through door.

Place handle on stand, inserting Ferrules into stand.

Tighten Grub Screws



Entrance Handle Fixing B2B

Date 2/02/2023




IMPORTANT! Mark and drill door from both sides.


Cut bolt to required length. Allow 15mm longer than door thickness.

Screw stands from behind to door.

Place handle on stand, inserting Ferrules into stand.

Tighten Grub Screws





Entrance Handle Rear Fixing


Date 2/02/2023

## **Installation Instructions**

Screw stand to door.

Place handle on stand, inserting Ferrules into stand.


Tighten Grub Screws





Entrance Handle Surface Fixing

Date 2/02/2023



## **Glass Fixing Installation Instructions**

Drill 13mm holes for bolt and plastic/rubber washer

Check dimensions carefully prior to drilling holes, each handle in our range is different.

Cut bolt to required lenght. Allow 30mm longer than the door thickness.

Screws stands together through door, including the plastic/rubber washers as shown in the drawing.

Place handle on stand, inserting the Ferrules into the stand.

Tighten Grub Screws.

Glass Fixing Kits with Rubber/Plastic parts are sold seperately

Rear Fixing Studs are availble when only one side requires a handle.

Entrance Handle Glass Fixing B2B

30/08/2024